

[WEARING](#)

[CHARGING](#)

[POWERING ON & PAIRING](#)

[MANUAL PAIRING](#)

[DUAL CONNECTIONS](#)

[BUTTON CONTROLS](#)

[AMBIENT SOUND](#)

[WIRED LISTENING](#)

[SIDETONE](#)

[RESET](#)

[LED LIGHT GUIDE](#)

[FIRMWARE UPDATE](#)

[SPECS](#)

[Regulations and Compliance Information](#)

Note: Discrepancies may exist between the product and the manual due to firmware and hardware updates. Please refer to the actual product for accurate usage.

APP



Google Play and the Google Play logo are trademarks of Google Inc.




Apple and the Apple logo are trademarks of Apple Inc.



Download the soundcore app to switch ambient sound modes, adjust EQ settings, update firmware, and explore more.


If your headphones cannot connect with the soundcore app, re-install the app or update it to the latest version in your mobile app store.

WEARING




Wear the headphones with the "L" logo on your left ear and "R" logo on your right ear. Adjust the length of the headband for a comfortable fit.

CHARGING



Fully dry off the headphones and USB-C charging port before charging.
Do not turn on your headphones while charging.
Use a certified USB-C charging cable and charger to prevent any damage.

POWERING ON & PAIRING




Press and hold the multi-function button for 2 seconds to power on. The headphones will automatically enter Bluetooth pairing mode when connecting for the first time.

Select **soundcore Q20i** * on your device's Bluetooth list when connecting for the first time.


*The device name may vary depending on the region.

MANUAL PAIRING



To manually enter Bluetooth pairing mode, power off the headphones and press the multi-function button for 5 seconds.

DUAL CONNECTIONS




To connect the headphones with two devices at the same time, ensure they are connected to only one device.

Then, press the multi-function button twice to pair with the second device.

You can also enable Dual Connections via the soundcore app. In the soundcore app, go to **Dual Connections > Enable Dual Connections > Connect New Device**.

• Dual Connections is enabled by default.

BUTTON CONTROLS




×1: Press once

×2: Press twice


2s: Press and hold for 2 seconds

AMBIENT SOUND




Active Noise Cancellation (ANC): Reduce unwanted background noise.
Transparency: Stay aware of your surroundings while listening to music.

WIRED LISTENING




Play audio on an external device by plugging in a 3.5mm AUX cable. Wired listening will automatically turn off Bluetooth mode.
*When using an AUX cable, the ANC function will be disabled.

SIDETONE




With the Sidetone feature on, you will hear your own voice loud and clear when making or receiving phone calls using the headphones.
*Sidetone feature is on by default. You can disable this feature via the soundcore app.

RESET




You might need to reset your headphones if you experience connectivity or function issues.
Delete the pairing history from your Bluetooth device first.
Press and hold the volume up and multi-function button simultaneously for 5 seconds until the LED slowly flashes red three times.

LED LIGHT GUIDE



	Flashing white rapidly
	Flashing red slowly
	Solid red
	Flashing blue rapidly
	Solid blue
	Light off

FIRMWARE UPDATE



You will be informed once the new version of firmware is detected when you connect the headphones with the app. Ensure the headphones are powered on and connected to a device until the firmware update is complete. During the update, avoid any usage and ensure stable access to the internet.

SPECS

Specifications are subject to change without notice.

Input	5 V --- 0.75 A
Rated output power	3.4 mW
Battery capacity	800 mAh
Charging time	2 hours
Playtime (with ANC off)	Up to 60 hours
Playtime (with ANC on)	Up to 40 hours
Driver size	40 mm
Frequency response	20 Hz - 40 kHz
Impedance	16 Ω
Bluetooth version	5.3
Bluetooth range	15 m / 49.2 ft

Variable 'x'	Range of variable	Content
Seventh	0-9 or A-F	Denotes the hardware version which is not effected on the safety compliance.
Eighth	8,9,A,B,C...	Denotes the year, 8 means 2018, 9 means 2019, A means 2020, B means 2021, C means 2022, and so on.
Ninth and tenth	01,02,03..	Denotes weeks, 01 means the first week in this year, 02 means the secondary week in this year, and so on.
Eleventh	1-7	Denotes date, 1 means Monday, 2 means Tuesday..., 7 means Sunday and so on.
The last five	00001-99999	Denotes serial No.

Regulations and Compliance Information

Hereby, Anker Innovations Limited declares that this device is in compliance with The Product Security and Telecommunications Infrastructure (Security Requirements for Relevant Connectable Products) Regulations 2023. For the Statement of Compliance, visit the website: <https://uk.soundcore.com/pages/psti-related>.

Note: The 'x' of SN Code: xxxxxxxxxxxxxx is a variable, see below table.